

JIAXING BAICHUAN PRINTER TECHNOLOGY CO., LTD

Addr: NO.51Huixin Road.Huimin Industrial Zone.Jiashan.Zhejiang Province.China Post: 314112 Tel:86-573-84641239 Fax:86-573-84641257 www.inks.com.cn,Email:sale@inks.com.cn,MSN:bcinks@hotmail.com

Products List

Item1-----Specific Dye Ink For EPSON Desktop Printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
ED-3A	8 06 31 03	C	T037/T039/T058/ T041/T018/T029	For Epson stylus C42UX/CX1500/C41UX/C43UX/C45/ME 100/ME 1/ 777/ 777i/ 680/685/1000ICS/ C60/C61/CX3100/C50/ C62/CX3200
	8 06 31 02	M		
	8 06 31 01	Y		
ED-3B	8 06 32 03	C	T0472/T0442	For Epson stylus C63/CX6300/C65/CX3500CX6500/C64/C66/C84/ C86/CX3400/CX6400/CX6600//CX3500/C83
	8 06 32 02	M	T0473/T0443	
	8 06 32 01	Y	T0474/T0444	
ED-3C	8 06 33 03	C	S020036/S020049/S020089/S020191/S020138/S0 20097/T014/T020/T005	For Epson Stylus Color740/760/800/850/850N/850Ne/860/1160/1520/40 0/440/ 600/640/660/670 Color300/200/500/480/450/C20/C40/880/880i/900N/98 0/980N
	8 06 33 02	M		
	8 06 33 01	Y		
ED-3D	8 06 34 03	C	T0322/T0422	For Epson Stylus C80/ C80N/C80WN/CX5100/CX5200/CX5300/CX5400/ C82N/C82WN/CX4500
	8 06 34 02	M	T0323/T0423	
	8 06 34 01	Y	T0324/T0424	
ED-3E	8 06 35 03	C	T0562/T0552	For Epson stylus photo RX430/RX420/RX520/R250/RX530
	8 06 35 02	M	T0563/T0553	
	8 06 35 01	Y	T0564/T0554	
ED-3G	8 06 37 03	C	T0632/T0602	Epson Stylus C67/C87/CX3700/ CX4700/CX4100/CX3810/CX4200/CX4800/CX5800F/ CX7800/C88/ CX3800/CX5700F
	8 06 37 02	M	T0633/T0603	
	8 06 37 01	Y	T0634/T0604	
ED-3K	8 06 41 03	C	T0762	For Epson stylus Me200/Me2/C58/CX2800/C57
	8 06 41 02	M	T0763	
	8 06 41 01	Y	T0764	
ED-3L	8 06 42 03	C	T5852/T5846	Epson PictureMate PM210/PM250/PM200/PM270
	8 06 42 02	M		
	8 06 42 01	Y		
ED-3LC	8 06 42 03	C	T5852/T5846	Epson PictureMate PM210/PM250/PM200/PM270(UV resistance dye ink)
	8 06 42 02	M		
	8 06 42 01	Y		
		k		
ED-3M	8 06 43 02	C	T0712/T0692/T0732/T0922	For Epson Stylus Photo RX5900 Epson Stylus /C79//C92/C110/C90/D92/D120/D78/D68/D88/CX500 0/6000/7000F/CX5900/CX3900/C90/CX4300/CX5500/ /CX4900/CX6900F/CX5600/CX5500/CX8300/CX7300/ CX5600,DX8400/DX8450/T20/TX200,
	8 06 43 02	M	T0713/T0693/T0733/T0923	
	8 06 43 01	Y	T0714/T0694/T0734/T0924	
ED-3P(New Products)	8 06 44 02	C	T6162/T6172/T6252/T6272	EPSON B308/B508/B300/B300DN/B500/B500DN(Original Inks:DURABrite Ultra Ink)
	8 06 44 02	M	T6163/T6173//T6253/T6273	
	8 06 44 01	Y	T6164/T6174/T6254/T6274	
		K	T6181/T6161/T6171/T6251/T6271	Epson Stylus B-500DN(T6251~T6254,T6271~T6274)
ED-5A	8 06 51 03	C	T008/T027	For Epson Photo790/870/875DC/890/895/915/ SP810/830/925/935
	8 06 51 02	M		
	8 06 51 01	Y		
	8 06 51 06	LC		
	8 06 51 05	LM		

Products List

ED-5B	8 06 52 03	C	T053/T001/S020110/S020193	For Epson stylus photo 1200/700/750/EX/750 for WebTV/ 710/720 /EX3
	8 06 52 02	M		
	8 06 52 01	Y		
	8 06 52 06	LC		
	8 06 52 05	LM		
ED-5C	8 06 53 03	C	T0482/T0492	For Epson stylus RX500/ R300/ R320/R300M/R200/RX600/RX620/R220/R340/ RX510/RX630/R310/R210/R230/R350/RX650
	8 06 53 02	M	T0483/T0493	
	8 06 53 01	Y	T0484/T0494	
	8 06 53 06	LC	T0485/T0495	
	8 06 53 05	LM	T0486/T0496	
ED-5H	8 06 58 03	C	T0332	Epson stylus Photo 950
	8 06 58 02	M	T0333	
	8 06 58 01	Y	T0334	
	8 06 58 06	LC	T0335	
	8 06 58 05	LM	T0336	
ED-5J	8 06 60 03	C	T009	For Epson Photo 1270/1280/1290
	8 06 60 02	M		
	8 06 60 01	Y		
	8 06 60 06	LC		
	8 06 60 05	LM		
ED-5K	8 06 61 03	C	T5592	For Epson Stylus Photo RX700
	8 06 61 02	M	T5593	
	8 06 61 01	Y	T5594	
	8 06 61 06	LC	T5595	
	8 06 61 05	LM	T5596	
ED-5L	8 06 62 04	K	T557	Epson Pictre Mate 100/500
	8 06 62 03	C		
	8 06 62 02	M		
	8 06 62 01	Y		
	8 06 62 23	B		
	8 06 62 12	R		
ED-5M	8 06 63 03	C	T0822/T0812/T0712/T0692/T0732/T0802	For Epson Stylus Photo RX590/R390/R290/R270/RX610/RX690/1410/R260/R265 Epson Stylus D78/CX5000/6000/7000F/CX5900/C79/CX3900/CX4900/CX6900F/ RX585/PX700W
	8 06 63 02	M	T0823/T0813/T0713/T0693/T0733/T0803	
	8 06 63 01	Y	T0824/T0814/T0714/T0694/T0734/T0804	
	8 06 63 06	LC	T0825/T0815/T0805	
	8 06 63 05	LM	T0826/T0816/T0806	
ED-5PC	8 06 66 04	K	T0821/T0811	For Epson Stylus Photo RX590/R390/R290/R270/RX610/RX690/1410/R260/R265 (Light resistance dye ink)
	8 06 66 03	C	T0822/T0812	
	8 06 66 02	M	T0823/T0813	
	8 06 66 01	Y	T0824/T0814	
	8 06 66 06	LC	T0825/T0815	
	8 06 66 05	LM	T0826/T0816	
ED-5KA (ED-5R)(New Products)	8 06 64 03	C	T559220	Epson Stylus Photo RX700
	8 06 64 02	M	T559320	
	8 06 64 01	Y	T559420	
	8 06 64 06	LC	T559520	
	8 06 64 05	LM	T559620	
ED-5T(New Products)	8 06 67 03	C	IC6CL50/IC6CL32	EPSON PM A870/PM-A920、PM-A820、PM-D870/PM-G850/PM-G4500/PM-A850/PM-D800/PM-D750/PM-D770/PM-G820/PM-G730/PM-G720/PM-G700/PM-G800
	8 06 67 02	M	IC6CL50/IC6CL32	
	8 06 67 01	Y	IC6CL50/IC6CL32	
	8 06 67 06	LC	IC6CL50/IC6CL32	
	8 06 67 05	LM	IC6CL50/IC6CL32	

Products List

ED-8A	8 06 81 03	C	T0542	Epson stylus Photo R800/R1800
	8 06 81 02	M	T0543	
	8 06 81 01	Y	T0544	
	8 06 81 23	B	T0549	
	8 06 81 12	R	T0547	
	8 06 81 09	MK	T0548	
	8 06 81 08	PK	T0541	
	8 06 81 10	GO	T0540	
ED-8B	8 06 82 09	MK	T0348	Epson stylus Photo 2100/2200
	8 06 82 03	C	T0342	
	8 06 82 02	M	T0343	
	8 06 82 01	Y	T0344	
	8 06 82 06	LC	T0345	
	8 06 82 05	LM	T0346	
	8 06 82 07	LK	T0347	
	8 06 82 08	PK	T0341	
ED-8E	8 06 85 03	C	T0872	Epson stylus Photo R1900
	8 06 85 02	M	T0873	
	8 06 85 01	Y	T0874	
	8 06 85 14	OR	T0879	
	8 06 85 12	R	T0877	
	8 06 85 09	MK	T0878	
	8 06 85 08	PK	T0871	
	8 06 85 10	GO	T0870	

Item 2-- Pigment ink for Epson Desktop

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EP-3A	9 06 31 04	K	T0461	For Epson stylus C63/CX6300/C65/CX3500CX6500
	9 06 31 03	C	T0472	
	9 06 31 02	M	T0473	
	9 06 31 01	Y	T0474	
EP-3B	9 06 2 04	K	T0321/T0421	For Epson Stylus C80/C80N/C80W/NX5100/CX5200/CX5300/CX5400/C 82N/C82WN
	9 06 32 03	C	T0322/T0422	
	9 06 62 02	M	T0323/T0423	
	9 06 32 01	Y	T0324/T0424	
EP-3C	9 06 33 04	K	T0561/T0551	For Epson StylusPhoto RX430/RX420/RX520/R250/RX530
	9 06 33 03	C	T0562/T0552	
	9 06 33 02	M	T0563/T0553	
	9 06 33 01	Y	T0564/T0554	
EP-3D	9 06 34 04	K	T0631/T0601	For Epson Stylus C67/C87/CX3700/CX4700/CX4100/CX3810/CX4200/ CX4800/CX5800F/CX7800/C88/CX3800
	9 06 34 03	C	T0632/T0602	
	9 06 34 02	M	T0633/T0603	
	9 06 34 01	Y	T0634/T0604	
EP-3F	9 06 35 04	K	T0711/T0691/T0731/T0921	For Epson Stylus Photo RX5900 Epson Stylus D92/D120/D78/D68/D88/CX5000/6000/7000F/CX5900 /C79/C110/CX3900/C90/CX4300/CX5500,DX8400/DX 8450/CX7300/T20/TX200
	9 06 35 03	C	T0712/T0692/T0732/T0922	
	9 06 35 02	M	T0713/T0693/T0733/T0923	
	9 06 35 01	Y	T0714/T0694/T0734/T0924	

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EP-3H(<i>New Products</i>)	9 06 38 04	K	T6161/T6171/T6251	For Epson Stylus Pro B308/B508 B300/B300DN/B500/B500DN
	9 06 38 03	C	T6162/T6172/T6252	
	9 06 38 02	M	T6163/T6173/T6253	
	9 06 38 01	Y	T6164/T6174/T6254	
EP-5A	9 06 51 04	K	T0481/T0491	For Epson stylus RX500/ R300/ R320/R300M/R200/RX600/RX620/R220/R340/ RX510/RX630/R310/R210/R230/R350/RX650
	9 06 51 03	C	T0482/T0492	
	9 06 51 02	M	T0483/T0493	
	9 06 51 01	Y	T0484/T0494	
	9 06 51 06	LC	T0485/T0495	
	9 06 51 05	LM	T0486/T0496	
EP-5B	9 06 52 04	K	T0331	For Epson stylus Photo 950
	9 06 52 03	C	T0332	
	9 06 52 02	M	T0333	
	9 06 52 01	Y	T0334	
	9 06 52 06	LC	T0335	
	9 06 52 05	LM	T0336	
EP-5C(<i>New Products</i>)	9 06 53 04	K	T007	For Epson stylus Photo 1290
	9 06 53 03	C	T009	
	9 06 53 02	M		
	9 06 53 01	Y		
	9 06 53 06	LC		
	9 06 53 05	LM		
EP-5D	9 06 54 04	K		T0821/T0811
	9 06 54 03	C	T0822/T0812	
	9 06 54 02	M	T0823/T0813	
	9 06 54 01	Y	T0824/T0814	
	9 06 54 06	LC	T0825/T0815	
	9 06 54 05	LM	T0826/T0816	
EP-5E	9 06 55 04	K	T079120/T0851	For Epson Stylus Photo 1400/1390
	9 06 55 03	C	T07922/TT0852	
	9 06 55 02	M	T079320/TT0853	
	9 06 55 01	Y	T079420/T0854	
	9 06 55 06	LC	T079520/T0855	
	9 06 55 05	LM	T079620/T0856	
EP-8A	9 06 81 03	C	T0542	For Epson Stylus Photo R800/R1800
	9 06 81 02	M	T0543	
	9 06 81 01	Y	T0544	
	9 06 81 23	B	T0549	
	9 06 81 12	R	T0547	
	9 06 81 09	MK	T0548	
	9 06 81 08	PK	T0541	
	9 06 81 10	GO	T0540	

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EP-8B	9 06 82 09	MK	T0348	For Epson Stylus Photo 2100/2200
	9 06 82 03	C	T0342	
	9 06 82 02	M	T0343	
	9 06 82 01	Y	T0344	
	9 06 82 06	LC	T0345	
	9 06 82 05	LM	T0346	
	9 06 82 07	LK	T0347	
	9 06 82 08	PK	T0341	
EP-8E	9 06 85 03	C	T0872	For Epson Stylus Photo R1900
	9 06 85 02	M	T0873	
	9 06 85 01	Y	T0874	
	9 06 85 14	OR	T0879	
	9 06 85 12	R	T0877	
	9 06 85 09	MK	T0878	
	9 06 85 08	PK	T0871	
	9 06 85 10	GO	T0870	
EP-1A	9 06 11 04	K	For Epson series	Epson Series
Item 3 -----Specific Dye ink for Epson Large format Printers				
EDPL-6A	8 16 61 03	C	T5492/T5140/T4630	For Epson Stylus Pro 10600/10000/7000/9000(T407-T411)
	8 16 61 02	M	T5493/T5130/T4620	
	8 16 61 01	Y	T5494/T5120/T4610	
	8 16 61 06	LC	T5495/T5160/T4650	
	8 16 61 05	LM	T5496/T5150/T4640	
	8 16 61 08	PK	T5491/T5110/T4600	
EDPL-8C	8 16 83 09	MK	T5438/T545200/T544200	Epson stylus Pro 7600/9600/4000/9400/7400/4400
	8 16 83 03	C	T5432/T545200/T544300	
	8 16 83 02	M	T5433/T545300/T544400	
	8 16 83 01	Y	T5434/T545400/T544500	
	8 16 83 06	LC	T5435/T545500/T544500	
	8 16 83 05	LM	T5436/T545600/T544600	
	8 16 83 07	LK	T5437/T545700	
	8 16 83 08	PK	T5431/T545100	
EDPL-8D	8 16 84 03	C	T0598/T5438/T5448/T5678/T5668	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880/3800
	8 16 84 02	M	T0592/T5642/T5652/T5622/T5632	
	8 16 84 01	Y	T0593/T5643/T5653/T5623/T5633	
	8 16 84 06	LC	T0594/T5644/T5654/T5624/T5634	
	8 16 84 05	LM	T0595/T5645/T5655/T5625/T5635	
	8 16 84 07	LK	T0596/T5646/T5656/T5626/T5636	
	8 16 84 08	PK	T0597/T5647/T5657/T5627/T5637	
	8 16 84 09	MK	T0591/T5641/T5651/T5621/T5631	
	8 16 84 11	LLK	T0599/T5649/T5659/T5629/T5639	

Products List

EDPL-9A	8 16 91 03	C	T5922	Epson 11880
	8 16 91 02	M	T5923	
	8 16 91 01	Y	T5924	
	8 16 91 06	LC	T5925	
	8 16 91 05	LM	T5926	
	8 16 91 07	LK	T5927	
	8 16 91 08	PK	T5921	
	8 16 91 09	MK	T5928	
	8 16 91 11	LLK	T5929	
EDPL-11A	8 16 A1 03	C	T6372/T5962/T6362	EPSON PRO7910/9910/7900/9900
	8 16 A1 02	M	T6373/T5963/T6363	
	8 16 A1 01	Y	T6374/T5964/T6364	
	8 16 A1 06	LC	T6375/T5965/T6365	
	8 16 A1 05	LM	T6376/T5966/T6366	
	8 16 A1 07	LK	T6377/T5967/T6367	
	8 16 A1 08	PK	T6371/T5961/T6361	
	8 16 A1 09	MK	T6378/T5968/T6368	
	8 16 A1 11	LLK	T6379/T5969/T6369	
	8 16 A1 14	OR	T637A/T596A/T636A	
8 16 A1 13	G	T637B/T596B/T636B		
ED-1A	8 06 11 04	K	Epson Series	Epson Series
ED-1H	8 06 18 04	K	Epson Series	Epson Series(new)

Item 4-- Pigment ink for Epson LFP Printers

Product Code	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EPPL-6A	9 16 61 03	C	T5492/T5140	For Epson Stylus Pro 10600/10000/7000/9000(T407-T411)ROLAND FJ-540 / FJ-740K
	9 16 61 02	M	T5493/T5130	
	9 16 61 01	Y	T5494/T5120	
	9 16 61 06	LC	T5495/T5160	
	9 16 61 05	LM	T5496/T5150	
	9 16 61 08	PK	T5491/T5110	
	9 16 61 09	MK	T5498	
EPPL-8A	9 16 81 09	MK	T5438	Epson stylus Pro 7600/9600/4000/9400
	9 16 81 03	C	T5432	
	9 16 81 02	M	T5433	
	9 16 81 01	Y	T5434	
	9 16 81 06	LC	T5435	
	9 16 81 05	LM	T5436	
	9 16 81 07	LK	T5437	
	9 16 81 08	PK	T5431	
EPPL-8B	9 16 82 03	C	T0592/T5642/T5622	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	9 16 82 02	M	T0593/T5643/T5623	
	9 16 82 01	Y	T0594/T5644/T5624	
	9 16 82 06	LC	T0595/T5645/T5625	
	9 16 82 05	LM	T0596/T5646/T5626	
	9 16 82 07	LK	T0597/T5647/T5627	
	9 16 82 08	PK	T0591/T5641/T5621	
	9 16 82 09	MK	T0598/T5438/T5668	
	9 16 82 11	LLK	T0599/T5649/T5629	

Products List

EPPL-9A	9 16 91 03	C	T5922	Epson 11880
	9 16 91 02	M	T5923	
	9 16 91 01	Y	T5924	
	9 16 91 06	LC	T5925	
	9 16 91 05	LM	T5926	
	9 16 91 07	LK	T5927	
	9 16 91 08	PK	T5921	
	9 16 91 09	MK	T5928	
	9 16 91 11	LLK	T5929	
EPPL-11A	9 16 A1 03	C	T6372/T5962/T6362	Epson 7910/9910/7900/9900
	9 16 A1 02	M	T6373/T5963/T6363	
	9 16 A1 01	Y	T6374/T5964/T6364	
	9 16 A1 06	LC	T6375/T5965/T6365	
	9 16 A1 05	LM	T6376/T5966/T6366	
	9 16 A1 07	LK	T6377/T5967/T6367	
	9 16 A1 08	PK	T6371/T5961/T6361	
	9 16 A1 09	MK	T6378/T5968/T6368	
	9 16 A1 11	LLK	T6379/T5969/T6368	
	9 16 A1 14	OR	T637A/T596A/T636A	
	9 16 A1 13	G	T637B/T596B/T636B	

Item 5 - Epson All Black Ink (Dye Ink)(Black & White Ink)

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
ED-4BW	8 06 04 04	BK	For Epson series(All black dye ink)	For Epson Four colors inkjet Printer
		KC		
	8 06 04 14	KM		
		KY		
ED-6BW	8 06 06 04	BK	For Epson series(All black dye ink)	For Epson Six colors inkjet Printer
		KC		
	8 06 06 14	KM		
		KY		
	8 06 06 24	KLC		
	KLM			

Item 6--Epson All Black Ink (Pigment Ink- Black & White Ink)

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EP-4BW	9 06 04 04	BK	For Epson Series(ALL BLACK)	For Epson four colors Inkjet Printer
		KC		
	9 06 04 14	KM		
		KY		
EP-6BW	9 06 06 04	BK	For Epson Series(ALL BLACK)	For Epson six colors Inkjet Printer
		KC		
	9 06 06 14	KM		
		KY		
	9 06 06 24	KLC		
	KLM			
EP-8ABW	9 16 08 04	PK	For Epson Series((All black series))	For Epson R1800/R800 Printer
	9 16 08 09	MK		
		KC		
	9 16 08 14	KM		
		KY		
	9 16 08 34	KB		
		KR		
9 16 08 44	GO			

Products List

EP-8BBW	9 16 18 04	PK	For Epson Series(All black series)	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	9 16 18 09	MK		
		KC		
	9 16 18 14	KM		
		KY		
	9 16 18 24	KLC		
		KLM		
	9 16 18 07	LK		
9 16 18 11	LLK			

Item 7 -Specific ink for CANON desktop & LFP printers (DYE & Pigment)

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
CD-3A	8 07 31 03	-C	BCI-24C	For Canon iP1000/1500/2000,i250/320/350/450/450x/455/470D/475D, 200/200x/300/330Photo,mp110/mp130mp360/mp370/mp390/mpc190/ mpc200Photo
	8 07 31 02	-M		
	8 07 31 01	-Y		
CD-3C	8 07 33 03	-C	BCI-21C	For Canon S100,BJC-2000/BJC-2100/5000/5100/5500,C70/75/80,FAX-B180C/B210C/B215C/B230C
	8 07 33 02	-M		
	8 07 33 01	-Y		
CD-3D	8 07 34 03	-C	BCI-15C	For Canon i70/i80
	8 07 34 02	-M		
	8 07 34 01	-Y		
CD-3E	8 07 35 03	-C	PG41/CL41C/CL38/CL-51C	For Canon MP150/170/450/MP145,iP1600/2200/IP1200,Canon PIXMA IP2500/IP1800/1700/1880/CANON IP2580/ip1900(PG37/PG40/407/CL41)
	8 07 35 02	-M		
	8 07 35 01	-Y		
CD-3F	8 07 36 03	-C	CLI-8C	For Canon Ip4200/ PIXMA IP6700D/IP3300/IP4300/IP4500/IP3500/Pixma 3300/ IP5300/PIXMAPro9000/PIXMA MP530
	8 07 36 02	-M	CLI-8M	
	8 07 36 01	-Y	CLI-8Y	
	8 07 36 06	-LC	CLI-8PC	
	8 07 36 05	-LM	CLI-8PM	
CD-3M(New Products)	8 07 43 03	-C	CLI-821C/521C	For CANON IP3680/IP4600/IP3600/Canon PIXMA MP540/MP560/MP620/MP640/MP630/MP980 PIXMA MX860
	8 07 43 02	-M	CLI-821M/521M	
	8 07 43 01	-Y	CLI-821Y/521Y	
CD-5A	8 07 51 03	-C	BCI-3eC	For Canon i550/i550x/i6500/i850,S400/S400x/S450/S4500/S500/S520/S520x/S530D/S600/ S630/S6300/S750, BJC-3000/BJC6000/BJC6100/BJC6200/ BJC6200S/BJC6500, MPC400/ MPC600F, MP700Photo/MP730Photo,C100
	8 07 51 02	-M	BCI-3eM	
	8 07 51 01	-Y	BCI-3eY	
	8 07 51 06	-LC	BCI-3ePC	
	8 07 51 05	-LM	BCI-3ePM	
CD-5B	8 07 52 03	-C	BCI-5	Canon BJC850/860/870
	8 07 52 02	-M		
	8 07 52 01	-Y		
	8 07 52 06	-LC		
	8 07 52 05	-LM		
CD-5E	8 07 55 03	-C	BCI-7E	For CANON PIXUS IP3100/IP3300/IP3500/IP4100/IP4200/IP4300/IP4500/IP5200R/IP6100D/IP6600D/IP6700D/7100/IP7500/IP8100/IP8600/IP9910/IX5000/IP4100R,PIXUS MP500/MP510/MP520/MP600/MP610/MP770/MP790/MP800/MP810/MP900/MP950/MP960/MP970/MP830/MP850/PIXUS PR09000
	8 07 55 02	-M		
	8 07 55 01	-Y		
	8 07 55 06	-LC		
	8 07 55 05	-LM		

Products List

(Product Code)	Reorder No.				(Color)	Cartridge No.	For use on Printer model
CD-8A	8	07	81	03	-C	BCI-6C	For CANON iP3000/4000/4000R/5000/6000D/8500,i560/865/905D/ 9100/ 950/965/990/9950, S800/820/ 820D/830D/900/9000,BJC-8200 Photo,MP 780/750/760
	8	07	81	02	-M	BCI-6M	
	8	07	81	01	-Y	BCI-6Y	
	8	07	81	06	-LC	BCI-6PC	
	8	07	81	05	-LM	BCI-6PM	
	8	07	81	12	-R	BCI-6R	
	8	07	81	13	-G	BCI-6G	
CD-1A(Dye)	8	07	11	04	-K	For Canon series	Dye black ink for Canon Inkjet printers
CD-1AC(Dye)	8	07	11	04	-K	For Canon series	Dye black ink for Canon Inkjet printers
CP-1A (Pigment)	9	07	11	04	K	BCI-3eBK/ BCI-24B/PGI-5BK/PGI821/PGI521	Pigment black ink for Canon Inkjet printers
CP-1B/ (Pigment)					K	BCI-3eBK/ BCI-24B/PGI-5BK/PGI821/PGI521	Pigment black ink for Canon Inkjet printers
Item 8 -Dye ink for Canon LFP printers							
CDPL-5A	8	17	51	03	C	PFI-102C (Dye type)	For Canon image PROGRAF IPF500/600/700/510/610/710(IPF810: PFI303, IPF820:PFI703)
	8	17	51	02	M	PFI-102M(Dye type)	
	8	17	51	01	Y	PFI-102Y (Dye type)	
	8	17	51	04	BK	PFI-102PBK (Dye type)	
CPPL-1A	9	17	51	09	MK	PFI-102MBK(Pigment type)	
CDPL-6A	8	17	61	03	C	BCI-1431C/BCI-1421C	For Canon Image Prograf W6400/8400
	8	17	61	02	M	BCI-1431M/BCI-1421M	
	8	17	61	01	Y	BCI-1451Y/BCI-1441Y	
	8	17	61	06	LC	BCI-1431PC/BCI-1421PC	
	8	17	61	05	LM	BCI-1431PM/BCI-1421PM	
	8	17	61	08	PK	BCI-1431BK/BCI-1421BK	
	8	17	61	09	MK	BCI-1451MBK/BCI-1441MBK	
CDPL-12A(12 colors)	8	17	B1	03	C	PFI-101C/PFI-701C	For Canon image PROGRAF IPF5000/5100/6100(PFI-103)/8000/9000(PFI- 701)/8100/9100/9110/8110(PFI-702)
	8	17	B1	02	M	PFI-101M/PFI-701M	
	8	17	B1	01	Y	PFI-101Y/PFI-701Y	
	8	17	B1	06	PC	PFI-101PC/PFI-701PC	
	8	17	B1	05	PM	PFI-101PM/PFI-701PM	
	8	17	B1	12	R	PFI-101R/PFI-701Red	
	8	17	B1	13	G	PFI-101G//PFI-701Green	
	8	17	B1	23	B	PFI-101B/PFI-701 Blue	
	8	17	B1	09	MBK	PFI-101MBK/PFI103MBK/PFI-701MBK/PFI- 702MBK	
	8	17	B1	08	BK	PFI-101BK/PFI103BK/PFI-701BK/PFI-702BK	
	8	17	B1	07	GY	PFI-101GY/PFI103GY/PFI-701GY/PFI-702GY	
8	17	B1	11	PGY	PFI-101PGY/PFI103PGY/PFI-701PGY/PFI- 702PGY		
CDPL-12A(8 colors)	8	17	B1	03	C	PFI-101C/PFI-701C	For Canon image PROGRAF 6000S/IPF8000S/IPF9000S/IPF8010S/IPF9010S
	8	17	B1	02	M	PFI-101M/PFI-701M	
	8	17	B1	01	Y	PFI-101Y/PFI-701Y	
	8	17	B1	06	PC	PFI-101PC/PFI-701PC	
	8	17	B1	05	PM	PFI-101PM/PFI-701PM	
	8	17	B1	09	MK	PFI-101MBK/PFI-701MBK	
	8	17	B1	08	BK	PFI-101BK/PFI-701BK	
	8	17	B1	07	GY	PFI-101GY/PFI-701GY	

Products List

Item 9 -Pigment ink for Canon LFP printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
CPPL-6A	9 17 61 03	-C	BCI-1431C/BCI-1421C	Canon image PROGRAF W6400/8400
	9 17 61 02	-M	BCI-1431M/BCI-1421M	
	9 17 61 01	-Y	BCI-1451Y/BCI-1441Y	
	9 17 61 06	-LC	BCI-1431PC/BCI-1421PC	
	9 17 61 05	-LM	BCI-1431PM/BCI-1421PM	
	9 17 61 08	-PK	BCI-1431BK/BCI-1421BK	
	9 17 61 09	-MK	BCI-1451MBK/BCI-1441MBK	
CPPL-12A	9 17 B1 03	C	PFI-101C/PFI-701C	For Canon image PROGRAF IPF5000/5100/6100(PFI-103)/8000/9000(PFI-701)/8100/9100/9110/8110(PFI-702)
	9 17 B1 02	M	PFI-101M/PFI-701M	
	9 17 B1 01	Y	PFI-101Y/PFI-701Y	
	9 17 B1 06	LC	PFI-101PC/PFI-701PC	
	9 17 B1 05	LM	PFI-101PM/PFI-701PM	
	9 17 B1 12	R	PFI-101R/PFI-701Red	
	9 17 B1 13	G	PFI-101G/PFI-701Green	
	9 17 B1 23	B	PFI-101B/PFI-701 Blue	
	9 17 B1 09	MBK	PFI-101MBK/PFI103MBK/PFI-701MBK/PFI-702MBK	
	9 17 B1 04	BK	PFI-101BK/PFI103BK/PFI-701BK/PFI-702BK	
	9 17 B1 07	GY	PFI-101GY/PFI103GY/PFI-701GY/PFI-702GY	
	9 17 B1 11	PGY	PFI-101PGY/PFI103PGY/PFI-701PGY/PFI-702PGY	
CPPL-12A(8 Colors)	9 17 B1 03	C	PFI-101C/PFI-701C	For Canon image PROGRAF 6000S/IPF8000S/IPF9000S/IPF8010S/IPF9010S
	9 17 B1 02	M	PFI-101M/PFI-701M	
	9 17 B1 01	Y	PFI-101Y/PFI-701Y	
	9 17 B1 06	LC	PFI-101PC/PFI-701PC	
	9 17 B1 05	LM	PFI-101PM/PFI-701PM	
	9 17 B1 09	MBK	PFI-101MBK/PFI103MBK/PFI-701MBK/PFI-702MBK	
	9 17 B1 04	BK	PFI-101BK/PFI103BK/PFI-701BK/PFI-702BK	
	9 17 B1 07	GY	PFI-101GY/PFI103GY/PFI-701GY/PFI-702GY	

Item 10 --Specific dye ink for HP desktop & LFP printers (DYE)

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HD-3A	8 08 31 04	-K	51645(No.45) / 6615(No.15)	For HP Color Copier 110 /120 , Color Copier 140i 170 , Color Copier 260 /270 , Deskjet 710i 740C , Deskjet 810i 812C/815C/816C , Deskjet 820 Cxi , Deskjet 825C , Deskjet 830 / 832C , Deskjet 840i 845 C , Deskjet 850i 855C , Deskjet 870Cxi , Deskjet 880i 899 C , Deskjet 1000 C (xi) , Deskjet 1100 C , Deskjet 1120 / 1125 C , Desk 1170 / 1175 C , Officejet 1150 Series , Officejet 1170 Series , Officejet Pro 1150 C , Office R Series , Office T Series , PSC 500 Series
	8 08 31 03	-C	C51641(No.41) / C1823(No.23) / C6625(No.17)	
	8 08 31 02	-MK		
	8 08 31 01	-Y		
HD-3B	8 08 32 04	-K	51626(No.26) / 51633(No.33)	2276A / 2277A / 2279A , 2279A Desk W riter , Designjet 200 / 220 , Deskjet 400 / 400L / 420C , DeskWriter 500C / 540C / 550C / 560C , Deskjet , Deskjet 300 port , Deskjet 310 , Deskjet 320 , Deskjet 330 / 340 C , Deskjet 500 , Deskjet 500C , Deskjet 510 / 520 , Deskjet 540 , Deskjet 550 C , Deskjet 560 C , Deskwriter 540 / 550C / 560C , Fax 200 , Fax 300 Series , Fax 700 Series , Fax 900 , Fax 950 , Officejet , Officejet 300 Series , Designjet 600
	8 08 32 03	-C	51625(No.25)	
	8 08 32 02	-M		
	8 08 32 01	-Y		

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HD-3C	8 08 33 04	-K	51645(No.45) / C6615(No.15)	Color Copier 180 / 190 , Color Copier 280 / 290 , Color Copier 310 , Deskjet 910; 919 C , Deskjet 920; 929 C , Deskjet 930; 939 C Deskjet 940; 949 C , Deskjet 950; 959 C , Deskjet 960; 969 C , Deskjet 970; 979 C , Deskjet 980; 989 C , Deskjet 990; 999 C , Deskjet 1180 Series , Deskjet 1220 C Series , Deskjet 1280 Series , Deskjet 3810 / 3816 / 3820 / 3822 , Deskjet 6122 / 6127 , Deskjet 9300 , Digital Copier 310 , Fax 1200 Series , Fax 1230 , Officejet 5100 Series , Officejet K Series , Officejet V Series , Photosmart 1000 / 1100 / 1200 / 1315 Series , PSC 700 Series , PSC 900 Series
	8 08 33 03	-C	C6578A/C1823d/51641A	
	8 08 33 02	-M		
	8 08 33 01	-Y		
HD-3D	8 08 34 04	-K	C9351(No.21) / CB334AE(No.54) / C8727(No.27) / C6656(No.56) / C8816(No.816)	915 Inkjet All-in-One printer/Deskjet 450 Series/3645/3650/3658/3668/3840/3920 /3930/ 3940 , Deskjet 5150 Color inkjet /Deskjet 5500/5600/5850/3558/Deskjet D1311/ D1320/D1330/D1341/D1360/1368 Deskjet 9800 Series , Deskjet D2320/D2330/D2338/D2345/D2360/Deskjet D2430/ D2445/D2460/ Deskjet D2468 , Deskjet F300 Series/Deskjet F2180/2110/2120/2128/2140/2185/ 2187/2188/Deskjet3320/3325/3550 / 3520/3535/3400 Series/Deskjet 3538/Deskjet F4100 Series/ Digital Copier 410/Fax 1240/1250/Officejet 1110/4100/4200/4300/ Officejet5500 Series/Officejet 5605 / 5605z /5608/5610/5610v/5610vi 5615/Officejet 6100/6110 Series/Officejet J3600/J5500 Series/Officejet Pro L7590 /Photosmart 7150/7200/7260/7345/7350/7450/7459/7550/7660/766 5/7760/7960/PSC1110/1200 Series/100 /130/230/145/245PSC 1215/PSC1300 Series/PSC 1400 Series/PSC 2100/2200Series/PSC 2170/2175/PSC2400/2500/
	8 08 34 03	-C	C9352(No.22)- (原HD3K) / C8728(No.28) / C6657(No.57) / C8817(No.817)	
	8 08 34 02	-M		
	8 08 34 01	-Y		
	8 08 34 04	-K	C6658(No.58)	
	8 08 34 06	-LC		
	8 08 34 05	-LM		
	8 08 34 08	-PK	C9359(No.59)	
	8 08 34 07	-MG		
8 08 34 11	-LG			
HD-3E	8 08 35 04	-K	51629(No.29) / C6614(No.20)	Deskjet 600 C/610 C/615 C/Deskjet 650; 659 C/Deskjet 640; 649 C/Deskjet 650; 659 C/ Deskjet 660; 666 C/Deskjet 670; 679 C/Deskjet 680; 682 C/Deskjet 690; 699 C/Deskwriter 600/Deskwriter 660C/670C/Fax 910/920/Fax 925xi/ Fax1000 Series/Fax 1040 Series/Fax 1050 Series/Officejet 500 Series/ Officejet 600 Series/Officejet 700 Series /PSC 300 Series
	8 08 35 03	-C	51649(No.49)	
	8 08 35 02	-M		
	8 08 35 01	-Y		
	8 08 35 04	-K	C1816(No.16)	
	8 08 35 06	-LC		
	8 08 35 05	-LM		
HD-3F	8 08 36 04	-K	C8765(No.94,338,131,852) / C9362(No.92,336,132,850) / C8767(No.96,339,130,853) / C9364(No.98,337,129)	For HP Deskjet 460 Mobile Series/ Deskjet5420v/5440/5442/Deskjet 5740/5743/5745/5748/Deskjet 5940 / 5940xi/5943/Deskjet 6520/6540/6543/6548,Deskjet 6840/6843,Deskjet6940/6940dt/6943,Deskjet 6980 / 6980dt/6983/6988/6988dt,Deskjet 9800Series,Deskjet D1400/DeskjetD4145/D4155/D4160/D4163,Officejet 6210/6215/Officejet6310/6315/Officejet7210O/fficejet7 310/7313/7410/7413,Office K7100/7103/7108 , Photosmart320/325/335/370/375/385/422/422v /422xi/ 428/428v/428xi/ 475/ 2575/2610/2613/ 2710/2713/8050/8150/8153/8450/8453/8700/8750/875 0gp/Photosmart C3180 , Photosmart C4180 , Photosmart D5160/ Photosmart Pro B8300 Printer Series/PSC 1500 Series/PSC 1610/PSC2350/2355 , Officejet H470 Mobile Printer Series
	8 08 36 03	-C	C8766(No.95,343,135,855) / C9363(No.97,344,134,857) / C9361(No.93,342,136,854)(原HD3J)	
	8 08 36 02	-M		
	8 08 36 01	-Y		
	8 08 36 04	-K	C9369(No.99,348,138,858) / C9365(No.101) (原 HD3J)	
	8 08 36 06	-LC		
	8 08 36 05	-LM		
	8 08 36 08	-PK		
	8 08 36 07	-MG	C9368(No.100) / C9360(No.102)	
8 08 36 11	-LG			

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HD-3G	8 08 37 04	-K	CB335(No.350,74,140) / CB336(No.350XL,74XL,140XL)	For HP Deskjet D1560 , Deskjet D4260 , Officejet J5780 / J5785 , Officejet J6400 Series , Officejet J6480 , Photosmart C4200 Series , Photosmart C4340 Series , Photosmart C4380 Series , Photosmart C5200 Series , Photosmart D5300 Series
	8 08 37 03	-C	CB337(351,75,141) / CB338(351XL,75XL,141XL)	
	8 08 37 02	-M		
	8 08 37 01	-Y		
	8 08 37 04	-K		
	8 08 37 06	-LC	C9369(No.99,348,138,858)	
	8 08 37 05	-LM	C9368(No.100)	
	8 08 37 08	-PK		
	8 08 37 07	-MG		
8 08 37 11	-LG			
HD-3H	8 08 38 04	-K	51606 A / 51639 A	Paintjet / Paintjet XL / Paintjet 3630 , Paintjet XL 300
	8 08 38 03	-C	51606 C / 51639 C	
	8 08 38 02	-M	51606 M / 51639 M	
	8 08 38 01	-Y	51606 Y / 51639 Y	
HD-3K	8 08 41 04	-K	CC640W(No.60) / CC641W(No.60XL)	For HP Deskjet D2500 Series , Deskjet F4200 Series
	8 08 41 03	-C	CC643W(No.60) / CC644W(No.60XL)	
	8 08 41 02	-M	CC643W(No.60) / CC644W(No.60XL)	
	8 08 41 01	-Y	CC643W(No.60) / CC644W(No.60XL)	
HD-3L	8 08 42 04	-K	C4844(No.10)	For HP 2000c Series , 2000c Professional Series , 2500c Pro Series , Designjet Color Pro GA / CAD
	8 08 42 03	-C	C4841(No.10)	
	8 08 42 02	-M	C4843(No.10)	
	8 08 42 01	-Y	C4842(No.10)	
HD-3M	8 08 43 03	-C	CB304(No.110)	For HP Photosmart A310 Series , Photosmart A320 Series , Photosmart A430 Series , Photosmart A440 Series , Photosmart A510 Series , Photosmart A520 Series , Photosmart A610 / A612 , Photosmart A616 / A617 / A618 , Photosmart A620 Series , Photosmart A710 Series , Photosmart A820 Series
	8 08 43 02	-M		
	8 08 43 01	-Y		
HD-3P	8 08 44 04	-K	C5011(No.14)	For HP Color Inkjet CP1160 , Digital Copier 610 , Officejet D Series , Officejet 7100 Series
	8 08 44 03	-C	C5010(No.14)	
	8 08 44 02	-M		
	8 08 44 01	-Y		
HD-3Q	8 08 45 04	-K	51640 A	For HP Designjet 250 C , Designjet 650 C / 650 PS , Designjet 430 , Designjet 330
	8 08 45 03	-C	51650 C	
	8 08 45 02	-M	51650 M	
	8 08 45 01	-Y	51650 Y	
HD-3R	8 08 46 04	-K	51640A / 51645A	For HP Designjet 350 C / 450 C / 455 CA / 488 CA , Designjet 750 C / 755 CM , Designjet 700
	8 08 46 03	-C	51644 C	
	8 08 46 02	-M	51644 M	
	8 08 46 01	-Y	51644 Y	
HD-3S	8 08 47 04	-K	51645(No.45)	For HP Color Copier 210 Series , Copy Jet / Copy Jet M , Designjet 230 , Deskjet 1200 C / PS , Deskjet 1600 C
	8 08 47 03	-C	51640C	
	8 08 47 02	-M	51640M	
	8 08 47 01	-Y	51640Y	
HD-3T	8 08 48 04	-K	364K/862K	For HP Photosmart D5468
	8 08 48 03	-C	364C/862C	
	8 08 48 02	-M	364M/862M	
	8 08 48 01	-Y	364Y/862Y	

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HD-4A (Dye ink) New Products	8 08 21 04	-K	C4902 AN (HP940)	HP officejet Pro8000/8500 (Original Ink: Pigment ink)
	8 08 21 03	-C	C4903 AN (HP940)	
	8 08 21 02	-M	C4904 AN (HP940)	
	8 08 21 01	-Y	C4905 AN (HP940)	
HP-4A (pigment ink)	9 18 21 04	-K	C4902 AN (HP940)	HP officejet Pro8000/8500
	9 18 21 03	-C	C4903 AN (HP940)	
	9 18 21 02	-M	C4904 AN (HP940)	
	9 18 21 01	-Y	C4905 AN (HP940)	
HD-5C	8 08 53 04	-K	C8719(No.02,363,177,801) / C8721(No.02,363,177,801)	For HP Photosmart 3210 / 3310 , Photosmart 8250 , Photosmart C5140 / C5150 / C5180 / C5185 / C5188 , Photosmart C6150 / C6180 / C6185 / C6188 , Photosmart C7180 , Photosmart C6200 Series , Photosmart C7200 Series , Photosmart C8150 / C8180 / C8183 / C8188 , Photosmart D6160 / D6163 / D6168 , Photosmart D7145 / D7155 / D7160 / D7163 / D7168 / Photosmart D7200 / D7400 , Photosmart D7345 / D7355 / D7360 / D7363 / D7368
	8 08 53 03	-C	C8771(No.02,363,177,801)	
	8 08 53 02	-M	C8772(No.02,363,177,801)	
	8 08 53 01	-Y	C8773(No.02,363,177,802)	
	8 08 53 06	-LC	C8774(No.02,363,177,802)	
	8 08 53 05	-LM	C8775(No.02,363,177,802)	
HD-1A	8 08 11 04	-K	HP series	For HP Series(Dye ink)

Item 11 Pigment black ink for HP Printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HP-1A	9 08 11 04	K	51629/51645/6615	Pigment black ink for HP Inkjet printers
HP-1D	9 08 14 04	K	51629/51645/6615	Pigment black ink for HP Inkjet printers
HP-1E	9 08 15 04	K	6656/8727	Pigment black ink for HP Inkjet printers
HP-1M	9 08 23 04	K	HP series	Pigment black ink for HP Inkjet printers

Item 12 ---Dye Ink and Pigment ink for HP large format Printers

HDPL-3A (HP82 原 HDPL-3C)	8 18 31 03	-C	C4836(No.11) / 4804(No.12) / C4911(No.82) / 4815(No.13)	For HP Business InkJet 1000 / 1100 / 1200 / 2200 / 2230 / 2250 / 2280 / 2300 / 2500 / 2600 / 2800 / CP1700 / 3000 Series , Color Inkjet CP1700 Series , Designjet 70 , Designjet 100/ 110 Plus /110 Plus NR , Designjet 500 / 500+ / 500PS / 500PS+ , Designjet 500 C , Designjet 800 Series , Officejet 9100 Series , Officejet Pro K850 , Officejet Pro K850dn
	8 18 31 02	-M	C4837(No.11) / C4805(No.12) / C4912(No.82) / 4816(No.13)	
	8 18 31 01	-Y	C4838(No.11) / C4806(No.12) / C4913(No.82) / 4817(No.13)	
	8 18 31 04	-K	C4844(No.10) / C4814(No.13)	
HDPL-3B(HD-3J)	8 18 32 03	-C	C9386(No.88) / C9391(No.88)/C4936(No.18)	For HP Officejet Pro K550/ Pro K550dtwn/ Pro K5400/ K5400tn/K5400dtn/ K5300/ Pro K8600 Series Officejet Pro Pro L7000/ L7400 Series/ L7580/7680/7780/L7380
	8 18 32 02	-M	C9387(No.88) / C9392(No.88)/C4937(No.18)	
	8 18 32 01	-Y	C9388(No.88) / C9393(No.88)/C4938(No.18)	
	8 18 32 04	-K	C9385(No.88) / C9395(No.88)/C4938(No.18)	
HDPL-3D	8 18 34 03	-C	C5061A(No.90)	For HP Designjet 4000/4500
	8 18 34 02	-M	C5063A(No.90)	
	8 18 34 01	-Y	C5065A(No.90)	
	9 18 34 04	-K	C5058A(No.90)	
HDPL-6A	8 18 61 03	-C	C4836(No.11)	For HP Designjet 120 / 120 nr , Designjet 10 / 20 / 50
	8 18 61 02	-M	C4837(No.11)	
	8 18 61 01	-Y	C4913(No.82)	
	8 18 61 06	-LC	C5017(No.84)	
	8 18 61 05	-LM	C5018(No.84)	
	8 18 61 04	-K	C5016(No.84)	

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HDPL-6B	8 18 62 03	-C	C9425(No.85) / C4931A / C4941A	For HP Designjet 30 / 90 / 90r / 90gp / 130 / 130nr 130gp ,
	8 18 62 02	-M	C9424(No.85) / C4932A / C4942A	
	8 18 62 01	-Y	C9427(No.85) / C4933A / C4943A	
	8 18 62 06	-LC	C9428(No.85) / C4934A / C4944A	
	8 18 62 05	-LM	C9429(No.85) / C4935A / C4945A	
	8 18 62 04	-K	C5016(No.84) / C4930A / C4940A	
HDPL-6C	8 18 63 03	-C	CD960A	For HP Designjet 5100
	8 18 63 02	-M	CD961A	
	8 18 63 01	-Y	CD962A	
	8 18 63 06	-LC	CD963A	
	8 18 63 05	-LM	CD964A	
	8 18 63 04	K	CD959A	
HDPL-6D (HDPL-6BA)	8 18 64 03	-C	C4931A(No.81)	For HP Designjet 5500 / 5000
	8 18 64 02	-M	C4932A(No.81)	
	8 18 64 01	-Y	C4933A(No.81)	
	8 18 64 06	-LC	C4934A(No.81)	
	8 18 64 05	-LM	C4935A(No.81)	
HPPL-6D(Pigment ink type)	9 18 64 03	C	C4931A(No.81)	For HP Designjet 5500 / 5000
	9 18 64 02	M	C4932A(No.81)	
	9 18 64 01	Y	C4933A(No.81)	
	9 18 64 06	LC	C4934A(No.81)	
	9 18 64 05	LM	C4935A(No.81)	
	9 18 64 04	BK		
HDPL-8A	8 18 81 03	-C	C9415(No.38)	For HP Photosmart Pro B8800 / Pro B8850 , Photosmart Pro B9180 / 9180gp
	8 18 81 02	-M	C9417(No.38)	
	8 18 81 01	-Y	C9419(No.38)	
	8 18 81 06	-LC	C9418(No.38)	
	8 18 81 05	-LM	C9416(No.38)	
	8 18 81 07	-LK	C9414(No.38)	
	8 18 81 09	-MK	C9412(No.38)	
	8 18 81 08	-PK	C9413(No.38)	
HDPL-8B	8 18 81 03	C	C9452A	For HP Designje Z2100
	8 18 81 02	M	C9453A	
	8 18 81 01	Y	C9454A	
	8 18 81 06	LC	C9490A	
	8 18 81 05	LM	C9455A	
	8 18 81 07	LG	C9451A	
	8 18 81 09	MK	C9448A	
	8 18 81 08	PK	C9449A	
HPPL-8B(Pigment ink type)	9 18 82 03	C	C9452A	For HP Designje Z2100
	9 18 82 02	M	C9453A	
	9 18 82 01	Y	C9454A	
	9 18 82 06	LC	C9490A	
	9 18 82 05	LM	C9455A	
	9 18 82 07	LG	C94551A	
	9 18 82 09	MK	C9448A	
	9 18 82 08	PK	C9449A	

Products List

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
HDPL-8C	8 18 81 03	C	C9467A(No.91)	For HP Designje 6100
	8 18 81 02	M	C9468A(No.91)	
	8 18 81 01	Y	C9469A(No.91)	
	8 18 81 06	LC	C9470A(No.91)	
	8 18 81 05	LM	C9471A(No.91)	
	8 18 81 07	LG	C9466A(No.91)	
	8 18 81 09	MK	C9464A(No.91)	
	8 18 81 08	PK	C9465A(No.91)	
HPPL-8C (Pigment ink type)	9 18 83 03	C	C9467A(No.91)	For HP Designje Z6100
	9 18 83 02	M	C9468A(No.91)	
	9 18 83 01	Y	C9469A(No.91)	
	9 18 83 06	LC	C9470A(No.91)	
	9 18 83 05	LM	C9471A(No.91)	
	9 18 83 07	LG	C9466A(No.91)	
	9 18 83 09	MK	C9464A(No.91)	
	9 18 83 08	PK	C9465A(No.91)	
HDPL-12A	8 18 B1 10	GE	C9459A(No.70)	For HP Designje Z3100/3200
	8 18 B1 02	M	C9453A(No.70)	
	8 18 B1 01	Y	C9454A(No.70)	
	8 18 B1 06	LC	C9390A(No.70)	
	8 18 B1 05	LM	C9355A(No.70)	
	8 18 B1 07	GY	C9450A(No.70)	
	8 18 B1 11	LG	C94551A(No.70)	
	8 18 B1 09	MK	C9448A(No.70)	
	8 18 B1 08	PK	C9449A(No.70)	
	8 18 B1 12	R	C9456A(No.70)	
	8 18 B1 13	G	C9457A(No.70)	
	8 18 B1 23	B	C9458A(No.70)	
HPPL-12A (Pigment ink type)	9 18 B1 10	GE	C9459A(No.70)	For HP Z3100/3200
	9 18 B1 02	M	C9453A(No.70)	
	9 18 B1 01	Y	C9454A(No.70)	
	9 18 B1 06	LC	C9390A(No.70)	
	9 18 B1 05	LM	C9355A(No.70)	
	9 18 B1 07	GY	C9450A(No.70)	
	9 18 B1 11	LG	C94551A(No.70)	
	9 18 B1 09	MK	C9448A(No.70)	
	9 18 B1 08	PK	C9449A(No.70)	
	9 18 B1 12	R	C9456A(No.70)	
	9 18 B1 13	G	C9457A(No.70)	
	9 18 B1 23	B	C9458A(No.70)	

Products List

Item 13 --Dye Ink For Lexmark Printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
LD-3A	8 09 31 03	-C	Lexmark 10N0026/LENOVO 13	For Lexmark X75/X1140/ X1150/ X1185/ X2250/ X1110/ X1155/Z13/ Z513/ Z515/ Z603/Z605/ Z615/Z23/ Z33/ Z25/Z35/ LENOVO 3310/3300/3210/3200/2210/2200/M720/M620E
	8 09 31 02	-M		
	8 09 31 01	-Y		
LD-3N	8 09 30 03	C	Lexmark series	Lexmark Universal ink
	8 09 30 02	M		
	8 09 30 01	Y		
LD-1A	8 09 11 04	-K	Lexmark 10N0016/LENOVO 11	For Lexmark X75/X1140/ X1150/ X1185/ X2250/ X1110/ X1155/Z13/ Z513/ Z515/Z603/Z605/ Z615/Z23/ Z33/ Z25/Z35/ LENOVO 3310/3300/3210/3200/2210/2200/M720/M620E
LP-1A(Pigment ink)	9 09 11 04	K	Lexmark 10N0016/LENOVO 11	Pigment ink for Lexmark Printers

Item 14---Dye ink for BROTHER Printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
BD-3A	8 05 31 03	-C	LC950C	For Brother MFC-210C/410CN/3240C/5440CN/DCP-110C/FAX-1840C
	8 05 31 02	-M	LC950M	
	8 05 31 01	-Y	LC950Y	
BD-3B	8 05 32 03	C	LC51C/LC960C/LC37C/LC38C	For Brother MFC-240C/DCP330C
	8 05 32 02	M	LC51M/LC960M/LC37M/LC38M	
	8 05 32 01	Y	LC51Y/LC960Y/LC37Y/LC38Y	
BD-3N	8 05 30 03	C	LC950C/LC51C/LC960C	For Brother MFC-210C/410CN/3240C/5440CN/DCP-110C/FAX-1840C/MFC-240C/DCP330C
	8 05 30 02	M	LC950M/LC51MLC960M	
	8 05 30 01	Y	LC950M/LC51Y/LC960M	
BD-1A(Dye ink)	8 05 11 04	-K	LC950BK	MFC-210C/410CN/3240C/5440CN/DCP-110C/FAX-1840C
BP-1A(Pigment ink)		K	Pigment ink for Brother Printers	

Item 22-----Cleaning Liquid

产品品名 (Product Name)	产品编号 (Code)	颜色 (Color)	墨匣型号 (Refill Cartridge)	适用机型 (For use on)
CBK-0A			For Canon /Hp/Lexmark black Ink cartridge	
CCL-0B	8 07 01 50	NON	For Canon /Hp/Lexmark Color Ink cartridge	for Canon /Hp/Lexmark dye ink
ECL-0A	8 06 01 50	NON	For Epson Black and color ink cartridge	For Epson dye ink (Non Color)
ECL-0B	8 06 02 50	LC	For Epson Black and color ink cartridge	For Epson dye ink (* Light Cyan)
UCL-0A	8 00 11 50	NON	For Epson/Canon/HP/Lexmark Ink cartridge	For Epson/Canon/Hp/Lexmark Dye ink
PCL-0A(Plain)	9 00 01 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
Cleaning Solution				
PCL-0B(powerful)	9 00 02 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
PCL-0C(Middle)	9 00 03 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series

Products List

Item 15 - Universal Ink

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
UD-6A	8 00 61 03	C	For Epson /Canon/HP/Lexmark Inkjet cartridge	For Epson /Canon/HP/Lexmark Inkjet printers
	8 00 61 03	M		
	8 00 61 01	Y		
	8 00 61 06	LC		
	8 00 61 05	LM		
	8 00 61 10	K		
UDP-6B	8 00 62 03	C	For Piezoelectric series	For Piezoelectric Ink-jet Printer
	8 00 62 02	M		
	8 00 62 01	Y		
	8 00 62 06	LC		
	8 00 62 05	LM		
	8 00 62 04	K		
UDT-6C	8 00 63 03	C	For Thermal series	For Thermal Ink-jet Printer
	8 00 63 02	M		
	8 00 63 01	Y		
	8 00 63 06	LC		
	8 00 63 05	LM		
	8 00 63 04	K		
UDE-1	8 06 11 03	C	T039/T029/T0472/T0562/T0632/T027/T009/ T0492/T0332/T5592	ForEpsonC43UX/C61/C63/C65/R250/C67/CX3700FO R EPSON 830U/R210/R230/R310/PHOTO950/1290/PM-A950
	8 06 11 02	M	T039/T029/T0473/T0563/T0633/T027/T009/ T0493/T0333/T5593	
	8 06 11 01	Y	T039/T029/T0474/T0564/T0634/T027/T009/ T0494/T0334/T5594	
	8 06 11 06	LC	T027/T009/T0495/T0335/T5595	
	8 06 11 05	LM	T027/T009/T0496/T0336/T5596	
UDC-1	8 07 11 03	C	BCI-24C/BCI-3C/BCI-6C/BCI-5C/CLI-8C	For Canon Printer Series
	8 07 11 02	M	BCI-24C/BCI-3M/BCI-6M/BCI-5M/CLI-8M	
	8 07 11 01	Y	BCI-24C/BCI-3Y/BCI-6Y/BCI-5Y/CLI-8Y	
	8 07 11 06	LC	BCI-3PC/BCI-6PC/BCI-5PC/CLI-8PC	
	8 07 11 05	LM	BCI-3PM/BCI-6PM/BCI-5PM/CLI-8PM	
	8 07 11 12	R	BCI-6R	
	8 07 11 13	G	BCI-6G	
UDH-1	8 08 11 03	C	c8728a,c6657a,c9352a,c9361w,c8766w,c93 63w	For HP Deskjet 5652/3325,D2360/F380, Deskjet 5440/5740/6540/6840/6548/6848
	8 08 11 02	M		
	8 08 11 01	Y		
	8 08 11 06	LC	c8727a c6656a	
	8 08 11 05	LM	C9351a,c9362wa	
	8 08 11 04	K	c8765wa	
UD-1A(Dye ink)	8 00 11 04	K	For Epson /Canon/HP/Lexmark Black inkjet Cartridge	For Epson /Canon/HP/Lexmark
UP-1A	9 00 11 04	K	Pigment ink type For Epson /Canon/HP/Lexmark Black inkjet Cartridge	For Epson /Canon/HP/Lexmark Inkjet printers
UPT-1A	9 01 11 04	K	For Thermal (Black pigment ink)	HP/canon/lexmark
UPT-1B	9 01 12 04	K	For Thermal (Black pigment ink)	HP/canon/lexmark
UPT-1C	9 01 13 04	K	For Thermal (Black pigment ink)	HP/canon/lexmark

Products List

Item 16--Dye ink for ROLAND Printers

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
RD-8A	7 19 81 03	-C	FPG-CY	For ROLAND FJ-540 / FJ-740K/Mimaki JV-22
	7 19 81 02	-M	FPG-MG	
	7 19 81 01	-Y	FPG-YE	
	7 19 81 06	-LC	FPG-LC	
	7 19 81 05	-LM	FPG-LM	
	7 19 81 12	-O	FPG-ORANGE	
	7 19 81 13	-G	FPG-GREEN	
	7 19 81 04	-K	FPG-BK	

Item 17--Pigment ink for Roland Mimaki

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
RP-8A	9 19 81 03	-C	FPG-CY	For ROLAND FJ-540 / FJ-740K/Mimaki JV-22
	9 19 81 02	-M	FPG-MG	
	9 19 81 01	-Y	FPG-YE	
	9 19 81 06	-LC	FPG-LC	
	9 19 81 05	-LM	FPG-LM	
	9 19 81 12	-R	FPG-OR	
	9 19 81 13	-G	FPG-GR	
	9 19 81 04	-K	FPG-BK	

Item 18---Sublimation ink

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
RSB-8A	7 19 81 03	C	FPG-CY	For ROLAND FJ-540 / FJ-740K/Mimaki JV-22
	7 19 81 02	M	FPG-MG	
	7 19 81 01	Y	FPG-YE	
	7 19 81 06	LC	FPG-LC	
	7 19 81 05	LM	FPG-LM	
	7 19 81 12	O	FPG-ORANGE	
	7 19 81 13	G	FPG-GREEN	
	7 19 81 04	K	FPG-BK	

Products List

Item 18---Sublimation ink

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
ESB-3A	7 06 31 04	K	T0631/T0601	For Epson Stylus C67/C87/CX3700/CX4700/CX4100/CX3810/CX4200/ CX4800/CX5800F/CX7800/C88/CX3800
	7 06 31 03	C	T0632/T0602	
	7 06 31 02	M	T0633/T0603	
	7 06 31 01	Y	T0634/T0604	
ESB-3B	7 06 32 04	K	T037/T039/T058/ T041/T018/T029	For Epson stylus C42UX/CX1500/C41UX/C43UX/C45/ME 100/ME 1/ 777/ 777i/ 680/685/1000ICS/ C60/C61/CX3100/C50/ C62/CX3200
	7 06 32 03	C		
	7 06 32 02	M		
	7 06 32 01	Y		
ESB-3C	7 06 33 04	K	T0711/T0691/T0731/T0921	For Epson Stylus Photo RX5900 Epson Stylus D92/D120/D78/D68/D88/CX5000/6000/7000F/CX5900 /C79/C110/CX3900/C90/CX4300/CX5500,DX8400/DX 8450
	7 06 33 03	C	T0712/T0692/T0732/T0922	
	7 06 33 02	M	T0713/T0693/T0733/T0923	
	7 06 33 01	Y	T0714/T0694/T0734/T0924	
ESB-5A	7 06 51 04	K	T0481/T0491/T0821/T0811	For Epson stylus RX500/ R300/ R320/R300M/R200/RX600/RX620/R220/R340/ RX510/RX630/R310/R210/R230/R350/RX650/RX590/ R260/R265/R270/R390/R290
	7 06 51 03	C	T0482/T0492/T0822/T0812	
	7 06 51 02	M	T0483/T0493/T0823/T0813	
	7 06 51 01	Y	T0484/T0494/T0824/T0814	
	7 06 51 06	LC	T0485/T0495/T0825/T0815	
	7 06 51 05	LM	T0486/T0496/T0826/T0816	
ESB-8A	7 16 81 03	C	T5438	Epson stylus Pro 7600/9600/4000/9400
	7 16 81 02	M	T5432	
	7 16 81 01	Y	T5433	
	7 16 81 06	LC	T5434	
	7 16 81 05	LM	T5435	
	7 16 81 07	LK	T5436	
	7 16 81 08	PK	T5437	
	7 16 81 09	MK	T5431	
ESB-8B	7 16 82 03	C	T0592/T5642/T5622	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	7 16 82 02	M	T0593/T5643/T5623	
	7 16 82 01	Y	T0594/T5644/T5624	
	7 16 82 06	LC	T0595/T5645/T5625	
	7 16 82 05	LM	T0596/T5646/T5626	
	7 16 82 07	LK	T0597/T5647/T5627	
	7 16 82 08	PK	T0591/T5641/T5621	
	7 16 82 09	MK	T0598/T5438/T5668	
	7 16 82 11	LLK	T0599/T5649/T5629	
ESB-8C	7 16 83 03	C	T0542	For Epson stylus Photo R800/R1800
	7 16 83 02	M	T0543	
	7 16 83 01	Y	T0544	
	7 16 83 23	B	T0549	
	7 16 83 12	R	T0547	
	7 16 83 09	MK	T0548	
	7 16 83 08	PK	T0541	
	7 16 83 10	GO	T0540	
RSB-8A	7 19 81 03	C	FPG-CY	For ROLAND FJ-540 / FJ-740K/Mimaki JV-22
	7 19 81 02	M	FPG-MG	
	7 19 81 01	Y	FPG-YE	
	7 19 81 06	LC	FPG-LC	
	7 19 81 05	LM	FPG-LM	
	7 19 81 12	O	FPG-ORANGE	
	7 19 81 13	G	FPG-GREEN	
	7 19 81 04	K	FPG-BK	

Products List

Item 19-- Textile ink

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
ET-3A	5 06 31 04	K	T0631/T0601/T0471/T0441	Epson Stylus C63/CX6300/C65/CX3500/CX6500/C64/C66/C84/ C86/CX3400/CX6400/CX6600/C67/C87/CX3700/ CX4700/CX4100/CX3810/CX4200/CX4800/CX5800F/ CX7800/C88/ CX3800/CX5700F
	5 06 31 03	C	T0632/T0602/T0472/T0442	
	5 06 31 02	M	T0633/T0603/T0473/T0443	
	5 06 31 01	Y	T0634/T0604/T0474/T0444	
ET-3B	5 06 32 04	K	T0711/T0691/T0731/T0921	For Epson Stylus Photo RX5900 Epson Stylus D92/D120/D78/D68/D88/CX5000/6000/7000F/CX5900 /C79/C110/CX3900/C90/CX4300/CX5500,DX8400/DX 8450
	5 06 32 03	C	T0712/T0692/T0732/T0922	
	5 06 32 02	M	T0713/T0693/T0733/T0923	
	5 06 32 01	Y	T0714/T0694/T0734/T0924	
ET-5A	5 06 51 04	K	T0481/T0491/T0821/T0811	For Epson stylus RX500/ R300/ R320/R300M/R200/RX600/RX620/R220/R340/ RX510/RX630/R310/R210/R230/R350/RX650/RX590/ R260/R265/R270/R390/R290
	5 06 51 03	C	T0482/T0492/T0822/T0812	
	5 06 51 02	M	T0483/T0493/T0823/T0813	
	5 06 51 01	Y	T0484/T0494/T0824/T0814	
	5 06 51 06	LC	T0485/T0495/T0825/T0815	
	5 06 51 05	LM	T0486/T0496/T0826/T0816	
ET-5B	5 06 52 04	K	T009	For Epson Photo 1290
	5 06 52 03	C		
	5 06 52 02	M		
	5 06 52 01	Y		
	5 06 52 06	LC		
	5 06 52 05	LM		
ET-8A	5 16 81 09	MK	T5438	Epson stylus Pro 7600/9600/4000/9400
	5 16 81 03	C	T5432	
	5 16 81 02	M	T5433	
	5 16 81 01	Y	T5434	
	5 16 81 06	LC	T5435	
	5 16 81 05	LM	T5436	
	5 16 81 07	LK	T5437	
	5 16 81 08	PK	T5431	
ET-8B	5 16 82 03	C	T0542	Epson stylus Photo R800/R1800
	5 16 82 02	M	T0543	
	5 16 82 01	Y	T0544	
	5 16 82 23	B	T0549	
	5 16 82 12	R	T0547	
	5 16 82 09	MK	T0548	
	5 16 82 08	PK	T0541	
	5 16 82 10	GO	T0540	
ET-8C	5 16 83 03	C	T0592/T5642/T5622	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	5 16 83 02	M	T0593/T5643/T5623	
	5 16 83 01	Y	T0594/T5644/T5624	
	5 16 83 06	LC	T0595/T5645/T5625	
	5 16 83 05	LM	T0596/T5646/T5626	
	5 16 83 07	LK	T0597/T5647/T5627	
	5 16 83 08	PK	T0591/T5641/T5621	
	5 16 83 09	MK	T0598/T5438/T5668	
	5 16 83 11	LLK	T0599/T5649/T5629	

Item 22-----Cleaning Liquid

PCL-0A(Plain)	9 00 01 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
-----------------	------------	-----	-------------------------------------	--

Products List

Item 20 --ART-PAPER Ink for Art paper/printing paper

(Product Code)	Reorder No.	(Color)	Cartridge No.	For use on Printer model
EA-5A	2 11 51 03	C	T0481/T0491/T0821/T0811	For Epson stylus RX500/ R300/ R320/R300M/R200/RX600/RX620/R220/R340/ RX510/RX630/R310/R210/R230/R350/RX650/RX590/ R260/R265/R270/R390/R290
	2 11 51 02	M	T0482/T0492/T0822/T0812	
	2 11 51 01	Y	T0483/T0493/T0823/T0813	
	2 11 51 06	LC	T0484/T0494/T0824/T0814	
	2 11 51 05	LM	T0485/T0495/T0825/T0815	
	2 11 51 04	K	T0486/T0496/T0826/T0816	
EA-8A	2 11 81 03	C	T0592/T5642/T5622	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	2 11 81 02	M	T0593/T5643/T5623	
	2 11 81 01	Y	T0594/T5644/T5624	
	2 11 81 06	LC	T0595/T5645/T5625	
	2 11 81 05	LM	T0596/T5646/T5626	
	2 11 81 07	LK	T0597/T5647/T5627	
	2 11 81 08	PK	T0591/T5641/T5621	
	2 11 81 09	MK	T0598/T5438/T5668	
2 11 81 11	LLK	T0599/T5649/T5629		
EA-8B	2 11 82 03	C	T5432	Epson stylus Pro 7600/9600/4000/9400
	2 11 82 02	M	T5433	
	2 11 82 01	Y	T5434	
	2 11 82 06	LC	T5435	
	2 11 82 05	LM	T5436	
	2 11 82 07	LK	T5437	
	2 11 82 08	PK	T5431	
	2 11 82 09	MK	T5438	
EA-8C	2 11 83 03	C	T0542	Epson stylus Photo R800/R1800
	2 11 83 02	MK	T0543	
	2 11 83 01	Y	T0544	
	2 11 83 23	B	T0549	
	2 11 83 12	R	T0547	
	2 11 83 09	MK	T0548	
	2 11 83 08	PK	T0541	
	2 11 83 10	GO	T0540	

Item 22-----Cleaning Liquid

产品品名 (Product Name)	产品编号 (Code)	颜色 (Color)	墨匣型号 (Refill Cartridge)	适用机型 (For use on)
CBK-0A			For Canon /Hp/Lexmark black Ink cartridge	
CCL-0B	8 07 01 50	NON	For Canon /Hp/Lexmark Color Ink cartridge	for Canon /Hp/Lexmark dye ink
ECL-0A	8 06 01 50	NON	For Epson Black and color ink cartridge	For Epson dye ink (Non Color)
ECL-0B	8 06 02 50	LC	For Epson Black and color ink cartridge	For Epson dye ink (* Light Cyan)
UCL-0A	8 00 11 50	NON	For Epson/Canon/HP/Lexmark Ink cartridge	For Epson/Canon/HP/Lexmark Dye ink
PCL-0A(Plain)	9 00 01 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series

Cleaning Solution

PCL-0B(powerful)	9 00 02 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
PCL-0C(Middle)	9 00 03 50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series

Products List

Item 21--- (Oil Dye ink)

产品品名 (Product Name)	产品编号 (Code)				颜色 (Color)	墨匣型号 (Refill Cartridge)	适用机型 (For use on)
OD-6A	4	06	61	04	K	EPSON	For Epson stylus Pro 10600/10000 For ROLAND FJ-540 / FJ-740K/Mimaki JV-22
	4	06	61	03	C		
	4	06	61	02	M		
	4	06	61	01	Y		
	4	06	61	06	Y		
	4	06	61	05	Y		
OD-8A	4	06	81	04	K	EPSON	Epson Stylus Photo R2400/ Pro 4800/Pro 7800/Pro9800/7880C/4880/9880
	4	06	81	03	C		
	4	06	81	02	M		
	4	06	81	01	Y		
	4	06	81	06	Y		
	4	06	81	05	Y		
	4	06	81	07	LK		
	4	06	81	11	LLK		
OD-8B	4	06	82	03	C	T0542	Epson stylus Photo R800/R1800
	4	06	82	02	M	T0543	
	4	06	82	01	Y	T0544	
	4	06	82	23	B	T0549	
	4	06	82	12	R	T0547	
	4	06	82	09	MK	T0548	
	4	06	82	08	PK	T0541	
	4	06	82	10	GO	T0540	

Item 22-----Cleaning Liquid

产品品名 (Product Name)	产品编号 (Code)				颜色 (Color)	墨匣型号 (Refill Cartridge)	适用机型 (For use on)
CBK-0A						For Canon /Hp/Lexmark black Ink cartridge	
CCL-0B	8	07	01	50	NON	For Canon /Hp/Lexmark Color Ink cartridge	for Canon /Hp/Lexmark dye ink
ECL-0A	8	06	01	50	NON	For Epson Black and color ink cartridge	For Epson dye ink (Non Color)
ECL-0B	8	06	02	50	LC	For Epson Black and color ink cartridge	For Epson dye ink (* Light Cyan)
UCL-0A	8	00	11	50	NON	For Epson/Canon/HP/Lexmark Ink cartridge	For Epson/Canon/Hp/Lexmark Dye ink
PCL-0A(Plain)	9	00	01	50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
Cleaning Solution							
PCL-0B(powerful)	9	00	02	50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series
PCL-0C(Middle)	9	00	03	50	NON	For Pigment/Sublimation base series	For Pigment /Sublimation/Textile Ink base series